

---

# CMCS Skip Bad Blocks User Manual

## General Description and Name

CMCS Skip Bad Blocks. This scheme breaks the device up into three sections.

## Relevant User Options

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

<http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = "CMCS Skip Bad Blocks"

Spare area : Please refer to "Description of common NAND special features.pdf". *Always set as "Enabled" for this BBM.* [Default 'Disabled']

Required good block area: Start block = "0" Please refer to "Description of common NAND special features.pdf".

Required good block area: Number of blocks = "0" Please refer to "Description of common NAND special features.pdf".

## Special Notes

The customer's data file should always contain the ECC and Spare Area data.

## Revision History

V1.0 June 12, 2009  
Create this spec.

## Appendix

You can get the file "Description of common NAND special features.pdf" from <http://ftp.dataio.com/FCNotes/BBM/>