
Skip with Check image ECC User Manual

General Description and Name

This scheme Implements the skip block method. Always identify block 0 as a good block. Check image file bad block mark except block 0.

Relevant User Options

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

<http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = "Skip with Check image ECC"

Spare area = "Enable"

Check BadBlock Marker in Data File : Please refer to "Description of common NAND special features.pdf". *Normally set as "Disabled" for this BBM.*[Default 'Enabled']

Special Notes

- This BBM PC file should contain the OOB(spare areas).

Revision History

V1.0 Date: 2012-02-08

Create this spec.

V1.1 Date: 2012-02-08

Add Special feature.

Appendix

You can get the file "Description of common NAND special features.pdf" from

<http://ftp.dataio.com/FCNotes/BBM/>