

---

# **HyundaiTelecom User Manual**

## **General Description and Name**

HyundaiTelecom is Reserved Block Area style BBM.  
BMI(Block Map Information) block is recorded the last two blocks.

## **Relevant User Options**

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

<http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = "HyundaiTelecom"

Spare area : "Enabled"

Other options set default value.

## **Special Notes**

Spare data includes in image.  
Bad Blocks are mapped to Reserved Block Area and it is recorded in BMI blocks.  
BMI Block is recorded the last two blocks.

## **Revision History**

V1.0 2011. 02. 14

## **Appendix**

You can get the file "Description of common NAND special features.pdf" from <http://ftp.dataio.com/FCNotes/BBM/>