
Skip End Free Pages User Manual

Use skip bad block scheme. Any free pages at the end of the image will be dropped.

Relevant User Options

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

<http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = " Skip End Free Pages "

Spare Area = " Disabled "

Error bits allowed in one page: How many error bits allowed within one page while verify, this depends on the ECC method. [Normally required, default is 0].

Revision History

V1.0 02/23/2018
Initial release

Appendix

You can get the file " Description of common NAND Special Features.pdf" from <http://ftp.dataio.com/FCNotes/BBM/>