

---

## **Skip with Segger Emfile User Manual**

### **General Description and Name**

This scheme implements the skip method and write first block using segger ECC256 and other blocks using Micron hardware ECC.

### **Relevant User Options**

The following special features on the special features tab apply to this scheme. The default values might work in some cases but please make sure to set the right value according to your system.

Please note only the below special feature items are related to this scheme and ignore any others. If any of below items doesn't exist, please check whether the right version has been installed or contact Data I/O for support by submitting Device Support Request through this address:

<http://www.dataio.com/support/dsr.asp>

Bad Block Handling Type = "Skip with Segger Emfile"

Spare area : Please refer to "Description of common NAND special features.pdf". *Normally set as "Enable" for this BBM.* [Default 'Disabled']

### **Special Notes**

If you want to know other settings, please get document "[Description of common NAND special features.pdf](#)" from our ftp site.

### **Revision History**

V1.0 Date 2015-09-11  
Create this spec.

### **Appendix**

You can get the file "Description of common NAND special features.pdf" from <http://ftp.dataio.com/FCNotes/BBM/>